INSERT BOTH ARMS, LIFT LEVERS AND TURN BOTH TO THE RIGHT.